



5XTC0: Using the NanoVNA

FEBRUARY, 2022

Meerten Versluis and Anouk Hubrechen

Topics

- **How to calibrate your NanoVNA?**
- Changing your plot display
- Using NanoVNASaver
- Common bugs when using the NanoVNA

How to calibrate the NanoVNA?

Calibration standards



Load



Thru



Short



Open

How to calibrate the NanoVNA



Connect your SMA cables



Please take care of the connectors and the device!

Only rotate the outer ring of the connector, not the cable itself because you can damage the connectors!

You can do this by holding the cable still and rotate the outer ring



How to calibrate the NanoVNA

Set the frequency range of interest


In this example set the frequency range from 400-1500 MHz

Start frequency

Stimulus → Start → 400M

Stop frequency

Stimulus → Stop → 1500M




How to calibrate the NanoVNA

Performing calibration

Go through all calibration steps in order to calibrate for all error terms!

1. Reset previous calibration

Cal → Reset




How to calibrate the NanoVNA

Performing calibration

Go through all calibration steps in order to calibrate for all error terms!

2. Calibrate with standards

Cal → Calibrate



How to calibrate the NanoVNA

Performing calibration

Go through all calibration steps in order to calibrate for all error terms!

3. Calibrate with standards

Connect the OPEN standard to the SMA cable on port CH0
Cal→Calibrate→Open

Note: the standard should now be highlighted in black (not visible in figure)



How to calibrate the NanoVNA

Performing calibration

Go through all calibration steps in order to calibrate for all error terms!

4. Calibrate with standards

Connect the SHORT standard to the SMA cable on port CH0
Cal → Calibrate → Short

Note: the standard should now be highlighted in black (not visible in figure)



How to calibrate the NanoVNA

Performing calibration

Go through all calibration steps in order to calibrate for all error terms!

5. Calibrate with standards

Connect the LOAD standard to the SMA cable on port CH0

Cal → Calibrate → Load

Note: the standard should now be highlighted in black (not visible in figure)



How to calibrate the NanoVNA

Performing calibration

Go through all calibration steps in order to calibrate for all error terms!

6. Calibrate with standards

Connect the LOAD standard to the SMA cable on port CH1

Cal → Calibrate → ISOLN

Note: the standard should now be highlighted in black (not visible in figure)



How to calibrate the NanoVNA

Performing calibration

Go through all calibration steps in order to calibrate for all error terms!

7. Calibrate with standards

Connect the THRU standard to the SMA cables on port CH0 and CH0
Cal→Calibrate→THRU

Note: the standard should now be highlighted in black (not visible in figure)



How to calibrate the NanoVNA


Performing calibration

Go through all calibration steps in order to calibrate for all error terms!

8. Calibration performed

Cal→Calibrate→DONE

Note: mind the black highlighted calibration steps



How to calibrate the NanoVNA


Performing calibration

Go through all calibration steps in order to calibrate for all error terms!

9. Save calibration data to be recalled

Cal→Save→SAVE X (where X can be any number from 1 to 4). Recommend you to save your calibration to SAVE1

Note: after calibration, data is automatically loaded and saved in SAVE0



How to calibrate the NanoVNA


Performing calibration

Go through all calibration steps in order to calibrate for all error terms!

10. Recall calibration data

Recall → Recall X (where X can be any number from 1 to 4). When saved to SAVE 1 you can select RECALL 1

Note: after calibration, data is automatically loaded and saved in SAVE0



How to calibrate the NanoVNA

How can you verify that your calibration is correct?


Connect your short/open/load standards and look at the smith chart.

Open

Note: Also look at your LOG/MAG plot, this should be $S_{11} \approx 0$ dB

Short

Note: Also look at your LOG/MAG plot, this should be $S_{11} \approx 0$ dB



Topics


- How to calibrate your NanoVNA?
- **Changing your plot display**
- Using NanoVNASaver
- Common bugs when using the NanoVNA

Changing your plot display

How can you change the traces and display on your nanoVNA?

Adding/Removing traces

Display → Trace




Changing your plot display

How can you change the traces and display on your nanoVNA?

Adding/Removing traces

Display → Trace → TRACE X
(X can be a number between 0 and 3)

Note: you can hide/view a trace when selecting it. When highlighted the trace is shown




Changing your plot display

How to change the plot display?

Change TRACE 0 to PHASE

Display → Trace → TRACE 0
→ BACK → FORMAT → PHASE

*Note: you can change any trace X
by any plot type
(LOGMAG/SMITH) by
reproducing these steps!*



Topics

- How to calibrate your NanoVNA?
- Changing your plot display
- **Using NanoVNASaver**
- Common bugs when using the NanoVNA

Using NanoVNASaver

Connect your device


Download NanoVNASaver application from CANVAS and open the application.

Note: you can also get the application from <https://github.com/NanoVNA-Saver/nanovna-saver/releases/tag/v0.3.10>

Select the *Connected to device* button in NanoVNASaver

Note: make sure the NanoVNA is connected to your pc when opening NanoVNASaver

Note: When connecting, the data that is currently loaded in the NanoVNA will be loaded in NanoVNASaver as well.




Using NanoVNASaver

Connect your device

When your device is connected successfully, it will show the box *Disconnected*

Note: color markers show the LOG/MAG and SMITH data at that particular frequency




Using NanoVNASaver

Performing another measurement

Connect another component to the NanoVNA

Data can again be viewed in NanoVNASaver by using *Sweep*




Using NanoVNASaver

Exporting data to Touchstone

Go to *Files...*

Your file can be exported to 1-port or 2-port network




Using NanoVNASaver

How to change the plot display?

Go to *Display setup...*

A new window will
pop-up



Using NanoVNASaver

How to change/add plot displays?

Default plots:

- S11 Smith
- S21 Polar
- S11 LOGMAG
- S21 LOGMAG

You can change the plots or you can add one.

Adding a phase plot

The screenshot shows the NanoVNASaver settings window. A red arrow points from the text 'Adding a phase plot' to the 'S11 Return Loss' dropdown in the 'Displayed charts' section.

Options

Return loss is: ☒ Negative ☐ Positive
Displays a thin line between data points

☐ Show lines
☐ Dark mode
Black background with white text

Sweep color

Second sweep color

Reference color

Second reference color

Point size px

Line thickness px

Marker size px

☐ Show marker numbers Displays the marker number next to the marker

☐ Filled markers Shows the marker as a filled triangle

Data point is: ☒ At the center of the marker ☐ At the tip of the marker

Displayed charts

S11 Smith Chart	S11 Return Loss	None
S21 Polar Plot	S21 Gain	None

Markers

Chart colors

☐ Use custom chart colors

Chart background

Chart foreground

Chart text

Font

Font size

Bands

☐ Show bands

Chart bands


VSWR Markers

VSWR Markers

Using NanoVNASaver

How to change the plot display?

Add a S21 phase plot







The image shows the 'Options' dialog box of NanoVNASaver. A red arrow points from the text 'Add a S21 phase plot' to the 'S21 Phase' dropdown menu in the 'Displayed charts' section.

Options

Return loss is: ☒ Negative ☐ Positive
Displays a thin line between data points
Black background with white text

☐ Show lines
☐ Dark mode

Sweep color 
Second sweep color 
Reference color 
Second reference color 

Point size px
Line thickness px
Marker size px

☐ Show marker numbers Displays the marker number next to the marker
☐ Filled markers Shows the marker as a filled triangle

Data point is: ☒ At the center of the marker ☐ At the tip of the marker




Displayed charts

S11 Smith Chart	S11 Return Loss	S21 Phase
S21 Polar Plot	S21 Gain	None

Markers

Chart colors


☐ Use custom chart colors

Chart background 
Chart foreground 
Chart text 


Font

Font size

Bands

☐ Show bands
Chart bands 


VSWR Markers

VSWR Markers 

Using NanoVNASaver

How to change the plot display?

Additional window is created in the main window



Using NanoVNASaver

Changing and adding markers

You can add a marker via *Display setup...*

Options

Return loss is: ☒ Negative ☐ Positive
Displays a thin line between data points

☐ Show lines
☐ Dark mode
Black background with white text

Sweep color

Second sweep color

Reference color

Second reference color

Point size px

Line thickness px

Marker size px

☐ Show marker numbers Displays the marker number next to the marker
☐ Filled markers Shows the marker as a filled triangle

Data point is: ☒ At the center of the marker ☐ At the tip of the marker

Displayed charts

S11 Smith Chart	S11 Return Loss	S21 Phase
S21 Polar Plot	S21 Gain	None

Markers

Chart colors

☐ Use custom chart colors

Chart background

Chart foreground

Chart text

Font

Font size

Bands

☐ Show bands

Chart bands


VSWR Markers

VSWR Markers

Using NanoVNASaver

Changing and adding markers

You can change the frequency of the marker by selecting and typing



Using NanoVNASaver

Using traces instead of data points only

You can add a traces via *Display setup...* → *Show lines*

Options

Return loss is: ☒ Negative ☐ Positive

☒ Show lines ☐ Dark mode

Sweep color

Second sweep color

Reference color

Second reference color

Point size px

Line thickness px

Marker size px

☐ Show marker numbers Displays the marker number next to the marker

☐ Filled markers Shows the marker as a filled triangle

Data point is: ☒ At the center of the marker ☐ At the tip of the marker

Displayed charts

S11 Smith Chart	S11 Return Loss	S21 Phase
S21 Polar Plot	S21 Gain	None

Markers

Add Remove Settings ...

Chart colors

☐ Use custom chart colors

Chart background

Chart foreground

Chart text

Font

Font size

Bands

☐ Show bands

Chart bands

Manage bands

VSWR Markers

VSWR Markers

None

Add ... Remove

Topics

- How to calibrate your NanoVNA?
- Changing your plot display
- Using NanoVNASaver
- **Common bugs when using the NanoVNA**



Common bugs when using the NanoVNA

Something went wrong with exporting your data to NanoVNASaver

Note: the same strange plot is probably also shown in your NanoVNA display

When you connect your device and the smith chart shows something similar to the figure on the left, then your data is probably not loaded correctly.

1. Disconnect NanoVNASaver
2. Remove the cable from the NanoVNA
3. Reconnect cable to the NanoVNA
4. Connect the NanoVNA on NanoVNASaver




Common bugs when using the NanoVNA

Resetting sweep after importing data to NanoVNASaver

When you connected your device to NanoVNASaver the NanoVNA sets its sweep on pause. You can visualize new data by resetting this.

Stimulus → Pause Sweep




Common bugs when using the NanoVNA

Resetting brightness after importing data to NanoVNASaver

When you connected your device to NanoVNASaver the NanoVNA sets its sweep on pause. You can visualize new data by resetting this.

Config→Brightness→ 3300 (for maximum brightness)



Common bugs when using the NanoVNA

Data cannot be loaded into NanoVNASaver

A warning message appears which restricts you to load data into NanoVNASaver

Recalibrate your NanoVNA again!

Follow the procedure on slides 6-15

Common bugs when using the NanoVNA

No traces are visible anymore

When your NanoVNA is completely empty and no traces are visible, check if these traces are turned off. Otherwise, recalibrate your NanoVNA again!

Follow the procedure on slides 6-15